



Floorboards:

1. The aft section runs on top of the frame floors from Frame-2560 aft, to blade off on the hull at about -4350. The floorboards angle down from aft to fwd.
2. The fwd section also sits on top of the frame floors from Frame -2650 fwd to Frame -1280. This section is level at 110 below the dwl.
3. Make the boards from 100 x 15 material with 20mm spaces between. The centre board can be 150 x 15.
4. Fit intermediate straps under boards between frames.
5. Arrange the boards in sections so that they can be removed reasonably easily.

Side Benches:

1. These run from 140 fwd of Frame -1920 to 120 aft of Frame -3840, stopping 5mm clear each side of mid thwart.
2. Inside edge of benches is 200 parallel inboard from inside face of carling.
3. Benches are formed from 4 off slats 20 thick x 40 wide, with 20 spaces between.
4. Benches are supported off frames by triangulated struts made from 35 x 20 timber. The inner ends are supported at the mid thwart by 75 x 15mm ply strips bonded under thwart.
5. Fit intermediate stiffener bearers (40 x 20) between frames, bonded under slats

Whisstock support@whisstock.com
boats and boat plans

Boat 055	Scale 1/10
Deck Plan	Date 20/05/2000
Floorboards	Plan No. 055/012/01
Side Benches	Issue No. 01 web
All dimensions in millimetres unless noted otherwise	

© bmarkweb Ltd 2002 All Rights Reserved