



- Notes:**
1. All dimensions are in millimetres unless otherwise noted.
  2. The Zero Point is the intersection of the Datum Water Line (dwl) with the forefoot.
  3. Positions are measured fwd and aft (marked "-") of the Zero Point.
  4. Heights are measured above and below (marked "-") the dwl.
  5. Offsets are measured each side of the fore-&-aft centreline (marked "C").
  6. Sections are designated "s" followed by their position.
  7. Waterlines are designated "wl" followed by their height.
  8. Buttocks are designated "b" followed by their offset.
  9. Diagonals are designated "d" followed by their start height on the centreline and their angle to it.
  10. Offsets on diagonals are measured down the angle of the diagonal.

 <b>Whisstock</b> boats and boat plans	support@whisstock.com	
	<b>Boat 073</b>	Scale 1/10
<b>Floorboards</b>	Date 20/05/2000	
	Plan No. 073/003/06	
	Issue No. 01 web	
© bmarkweb Ltd 2002 All Rights Reserved		All dimensions in millimetres unless noted otherwise