



General Notes:

1. The Zero Point is the intersection of the Datum Water Line (dwl) with the stemface.
2. Positions are measured fwd and aft (marked "-") of the Zero Point.
3. Heights are measured above and below (marked "-") the dwl.
4. Offsets are measured each side of the fore-&-aft centreline.
5. Waterlines are designated "wl" followed by their height.
6. Buttocks are designated "b" followed by their offset.
7. Diagonals are designated "d" followed by their start height on the centreline and their angle to it.
8. Offsets on diagonals are measured down the angle of the diagonal.
9. Offsets are to inside of skin unless noted otherwise.

 Whisstock boats and boat plans	support@whisstock.com	
	Boat 146 Longitudinal Structures Profile View	
Scale	1/10	
Date	20/05/2000	
Plan No.	146/003/01	
Issue No.	01 web	
All dimensions in millimetres unless noted otherwise		
© bmarkweb Ltd 2002 All Rights Reserved		