



General Notes:

1. The Zero Point is the intersection of the Datum Water Line (dwl) with the stemface.
2. Positions are measured fwd and aft (marked "-") of the Zero Point.
3. Heights are measured above and below (marked "-") the dwl.
4. Offsets are measured each side of the fore-&-aft centreline.
5. Waterlines are designated "w" followed by their height.
6. Buttocks are designated "b" followed by their offset.
7. Diagonals are designated "d" followed by their start height on the centreline and their angle to it.
8. Offsets on diagonals are measured down the angle of the diagonal.
9. Offsets are to inside of skin unless noted otherwise.

Whisstock boats and boat plans support@whisstock.com

Boat 146 Interior Layout	Scale 1/10
	Date 08/07/2007
	Plan No. 146/010/15
	Issue No. 08 web
All dimensions in millimetres unless noted otherwise	